




Bulletin HY30-5502-M1/UK

# Service Manual Series F1

Effective: June, 2006  
Supersedes: September, 1999

---



**List of contents****Page**

|   |    |
|---|----|
| Specifications, design and function ..... | 3  |
| Direction of rotation .....               | 4  |
| Operation check .....                     | 5  |
| Change of shaft seals.....                | 6  |
| Disassembling .....                       | 7  |
| Wear check.....                           | 8  |
| Assembling.....                           | 9  |
| Split view / spare parts .....            | 11 |

**Conversion factors**

|                   |                            |
|-------------------|----------------------------|
| 1 kg              | = 2.2046 lb                |
| 1 N               | = 0.22481 lbf              |
| 1 bar             | = 14.504 psi               |
| 1 l               | = 0.21997 UK gallon        |
| 1 l               | = 0.26417 US gallon        |
| 1 cm <sup>3</sup> | = 0.061024 in <sup>3</sup> |
| 1 m               | = 3.2808 feet              |
| 1 mm              | = 0.03937 in               |
| 9/5 °C + 32       | = °F                       |

**WARNING**

**FAILURE OR IMPROPER SELECTION OR IMPROPER USE OF THE PRODUCTS AND/OR SYSTEMS DESCRIBED HEREIN OR RELATED ITEMS CAN CAUSE DEATH, PERSONAL INJURY AND PROPERTY DAMAGE.**

This document and other information from Parker Hannifin Corporation, its subsidiaries and authorized distributors provide product and/or system options for further investigation by users having technical expertise. It is important that you analyze all aspects of your application, including consequences of any failure, and review the information concerning the product or system in the current product catalogue. Due to the variety of operating conditions and applications for these products or systems, the user, through its own analysis and testing, is solely responsible for making the final selection of the products and systems and assuring that all performance, safety and warning requirements of the application are met.


The products described herein, including without limitation, product features, specifications, designs, availability and pricing, are subject to change by Parker Hannifin Corporation and its subsidiaries at any time without notice.

**Offer of Sale**

Please contact your Parker representation for a detailed "Offer of Sale".

## Specifications

| Frame size | Displ. cm <sup>3</sup> /rev | Weight kg | Pressure bar |         | Shaft speed rpm |         | Oilflow l/min<br>Shaftspeed rpm |      |      |
|------------|-----------------------------|-----------|--------------|---------|-----------------|---------|---------------------------------|------|------|
|            |                             |           | Cont.        | Interm. | Cont.           | Interm. | 500                             | 1000 | 1500 |
| F1-20      | 19                          | 6,7       | 250          | 350     | 2300            | 3000    | 10                              | 20   | 30   |
| F1-30      | 28,1                        | 6,9       | 250          | 350     | 2000            | 2700    | 15                              | 30   | 45   |
| F1-40      | 38,7                        | 9,5       | 250          | 350     | 1800            | 2400    | 20                              | 40   | 60   |
| F1-60      | 58,2                        | 10        | 250          | 350     | 1500            | 2200    | 30                              | 60   | 90   |
| F1-80      | 78,2                        | 14        | 250          | 350     | 1300            | 2000    | 40                              | 80   | 120  |
| F1-110     | 110,1                       | 18        | 250          | 350     | 1300            | 1800    | 55                              | 110  | 165  |




## Design and function

F1 is a piston pump with spherical pistons (1) including piston rings (2). The pistons are working at the angle of 40° to the shaft (3). When the shaft rotates, the pistons move up and down in the cylinder barrel (4), forcing the oil to pass from the inlet port to the outlet in the end cap (5). A ring gear (6) connects the cylinder barrel to the drive shaft, causing these to rotate at the same speed.


A barrel support (7) with a spring presses the cylinder barrel against the end cap. An internal connection from the housing to the suction port eliminates a separate drain line to the tank. F1 is provided with shaft and connection flange that fits direct to PTO's with ZF standard.

On the barrel housing the text "Rotation" is found. An arrow on the end cap opposite this text shows the direction of rotation of the pump shaft.




### Change of Rotation of Direction

The position of the end cap determines the direction of rotation, and an arrow on the end cap opposite the text "Rotation" indicates the direction of rotation.




Pump fitted for left - hand rotation




Pump fitted for right - hand rotation

Change of direction of rotation, which means turning the end cap, is carried out as follows:  
Fasten the pump so that the connections point upwards.



1. Remove the four screws holding the end cap, ensuring that the end cap and body do not come apart. The end cap might be raised a little by the spring of the barrel support, but do not lift it because the interior parts may then be displaced, causing a breakdown when the pump is started.



2. Turn the end cap half a revolution.

3. Fasten the end cap.

Torques to be used:

F1-20, -30, -40, -60

60±10 Nm

F1-80, -110


90±10 Nm

## Operation Check

### Check of Shaft Seal

The pump has two shaft seals - the inner one sealing the hydraulic oil in the housing, and the outer one the transmission oil when the pump is fitted to a PTO. If any of the sealrings leak, the oil will come out through an indication hole.

Check that no oil is dripping out of the indication hole, when the pump is in operation. If there is a leakage from the sealrings, they must be exchanged, See chapter "Exchange of shaft seals".




Indication hole

### Checking the Flow from the Pump

The flow from the pump can be checked by means of a test instrument comprising a flowmeter and a relief valve.

Note: A heavy leakage can be caused by a worn-out pump, whereby high pressure oil will come out into the housing in such large quantities that the sealing might be damaged. If there is a steady stream of oil from the indication hole, the pump is probably damaged and will have to be replaced.

Connecton of test instrument



When the pump is running at about 800 - 1400 r.p.m. and is loaded up to 150 - 200 bar, the flow must not decrease by more than 10%.



Example:

An F1-40 running at 1225 r.p.m. gives - according to the flowmeter. - a flow of 48 l/min.

If the pump is loaded, the flow must not decrease by more than  $0,1 \times 48 = 4,8$  l / min, i.e. the flowmeter should indicated at least  $48 - 4,8 = 43,2$  l / min. If the flow drops below this limit, the pump is worn out and will have to be

## Service Procedures

### Exchange of shaft seals




Tool for fitting of shaft seals


1.  
Pull out the outer seal ring A, e.g. by means of a screwdriver by piercing the wall of the seal. Take care not to damage the sealing surface B of the shaft.
2.  
Loosen the retaining ring C.
3.  
Pull out the inner seal ring D in the same way as the outer one.
4.  
Check that the sealing surface of the shaft is undamaged. If damaged, the pump has to be taken apart and the slewe has to be replaced.
5.  
Push on the new inner sealring.
6.  
Fit the retaining ring. See to it, that the opening of the retaining ring is placed at the indication hole, which will otherwise be blocked.
7.  
Fill out the space between retaining ring and shaft with heat - resistant grease.
8.  
Fit the new outer seal ring.

## Disassembly


Fasten the pump in a vice.



1.  
Loosen the end cap and remove it.





2.  
Loosen the screws joining the bearing housing and the barrel housing, and remove the barrel housing.



3.  
Remove the cylinder barrel.
4.  
Mark piston and corresponding ball socket to enable correct location when reassembling.




5.  
Remove the pistons, which can be lifted out when held parallelly to the drive shaft.
6.  
Remove barrel support.



The laminated piston rings should always be replaced at a major overhaul (due to fatigue), and if the play between piston and new rings is more than 0,2 mm also the piston should be replaced.

7.

Place the bearing housing on a support, and knock cautiously on the shaft until it can be removed.



Remove the bearing from the shaft

## Checking and Replacement

Clean all parts when the pump has been disassembled. Check carefully for wear and damage. Replace all gaskets and seal rings.


If the oil flow from the F1 pump is less than normal, the following parts are likely to be worn:

- The surface facing the cylinder barrel on the end cap.
- The end surface of the cylinder barrel.
- The piston rings


Scores and marks on these parts will always decrease the performance of the pump. Always replace them by new




## Assembly




1. Remove the plug from the barrel housing.
2. Fit new seal rings in the bearing housing (see earlier instructions, page 6).
3. Fasten the bearing housing in a vice. Press the shaft assembly into the housing.
4. Fit the barrel support and the pistons into their respective ball cups.



5. Find the marked tooth on the shaft.




6. Find the marked tooth space on the cylinder barrel.



7. Position the cylinder barrel with its mark opposite the mark of the shaft, and enter the pistons into the cylinders and the barrel support into the centre bore.
8. Place a gasket on the barrel housing.



9.  
Slip the barrel housing over the cylinder barrel. Fit and tighten the screws.




10.  
Check through the inspection hole that the two marks are opposite each other. If not, correct this.

11.  
The backlash of the gear must be 0,05 - 0,30 mm . This play can be checked through the inspection hole, with a feeler guage.

The number of gaskets between end cap and bearing housing determines the backlash.

When assembling, use the same number of gaskets as found at the disassembly. If the number is unknown, try with 2 gaskets.

The number of gaskets determines the backlash




12.  
Fit the end cap so as to enable the correct direction of rotation. Tighten the screws lightly. Check that there is a backlash. If the backlash is unsufficient, fit more gaskets.

Tightening torques:

|                      |          |
|----------------------|----------|
| F1-20 / 30 / 40 / 60 | 35-45 Nm |
| F1-80 / 110          | 70-80 Nm |

13.  
Fit the seal washer and the plug at the inspection hole.



KOVANZ.CZ



**Parker Hannifin**  
Pump and Motor Division  
Flygmotorvägen 2  
SE-461 82 Trollhättan  
Sweden  
Tel: +46 (0)520 40 45 00  
Fax: +46 (0)520 371 05  
[www.parker.com](http://www.parker.com)